



# iPhone 5 Headphone jack for music remote control to listen to headphones

Detachment of jack plugs (eg the original Apple headphone) lead to conductive layer in the headphone jack. This affects the remote control of the music. Solution: Abrasion of the deposits with very fine abrasive paper

Written By: RustyOcean

## INTRODUCTION

Detachment of jack plugs (eg the original Apple headphone) lead to a conductive layer between the individual segments of the jack plug. This affects the music remote control (play, pause, song change).

## Step 1 — iPhone 5 Headphone jack for music remote control to listen to headphones



- **Step 1:** Carefully loosen and remove the dust in the headphone jack using soft tools (eg toothpicks).

## Step 2



- Roll a piece of very fine abrasive paper (approx. 1cm x 2cm) into a thin roll and carefully grind the deposits inside the headphone socket. Caution: Do not damage the round pins that make contact between the jack and the headphone jack.

Arbeite die Schritte in umgekehrter Reihenfolge ab, um dein Gerät wieder zusammenzubauen.

This document was last generated on 2017-07-19 06:41:58 AM.